


ISOZone Series		
Male Adapter (MACME x SCOKET)		
Part No	Nominal Size (in)	
336-020	2 - Inch	




ISOZone Series		
Elbow 90° (FACME x SOCKET)		
Part No	Nominal Size (in)	
307-020	2 - Inch	



ISOZone Series		
Elbow 90° (FACME x FACME)		
Part No	Nominal Size (in)	
308-020	2 - Inch	




ISOZone Series		
Tee (Socket x Socket x FACME)		
Part No	Nominal Size (in)	
302-020	2 - Inch	



Surge Guard Series		
Elbow 45° (Socket x Socket)		
Part No	Nominal Size (in)	
317-020	2 - Inch	

Example only – to illustrate LASCO ISOZone series Connectors in assembling a zone valve.



- ① ELBOW 90°, (FACME x FACME), LASCO MODEL # 308-020, (2) TWO REQUIRED.
- ② MALE ADAPTER, (MACME x SCOKET) LASCO, MODEL # 336-020, (2) TWO ARE HIDDEN, (5) FIVE REQUIRED.
- ③ TEE - 2", (SOCKET x SOCKET x FMACME) LASCO, MODEL # 302-020.
- ④ ELBOW 45° - 2", (SOCKET x SOCKET), LASCO SURGE GUARD PART # 317-020.
- ⑤ NIPPLE, BLANK BOTH ENDS, (3) THREE REQ'D, (1) HIDDEN.
- ⑥ NIPPLE, THREAD ONE END, SCH80, 2 REQ'D, CUT TO LENGTH.



## LASCO ISOZONE CONNECTOR FITTINGS WITH R.C.V.

N.T.S. USE LASCO ISO VALVE CONNECTOR FITTINGS FOR 2" REMOTE CONTROL ZONE VALVES.

DETAIL-FILE