


Outlet Locations

X = This outlet is connected to/controlled by a light switch in the kitchen and it should not be used by event vendors unless absolutely necessary. **DO NOT UNPLUG ANYTHING AHEAD PLUGGED INTO THE OUTLET!** The thick black cords that come from the ground are connected to the outside lighting and unplugging them will disable them.

LAYOUT --
 Scale for Pavillion & Terrace:
 □ = 5 feet diameter
 □ = 25 square feet



DIXON
 GALLERY & GARDENS
 HUGHES Pavilion